













## Chapter One Introduction



Currently, the price of most professional 51 simulator in the market is more than 2000yuan (about US\$300) and beginners often can not afford it. Meanwhile, a large volume of simulator designed with SST single chip solution is very slow and occupies much resources and it is not enough for real application. 51TRACER simulator is a brand new professional simulator developed by Xuelin Electronics, Shenzhen who owns the full intellectual property on it.

### Top ten innovations:

-  1. It adopts the latest high-tech air-class magnesium alloy case, and imported flannel fabric bag.
-  2. A large number of devices using the latest technology and all SMT installed. Adopt imported tantalum capacitor.
-  3. Comprehensive protection to avoid any possible mistakes. The power supply adopts fast-recovery insurance, even if short-circuit, it could be effectively protected. All IO ports are designed with anti-shock resistance and USB port is also designed with electrostatic prevention of the lightning strike.
-  4. Single USB interface, no extra power supply or serial port, real plug-in peripheral. Convenient for desktop or laptop without RS232 interface. This product adopts 3 chip structure, that is simulation chip + monitor chip + USB chip, which is a real individual simulator.
-  5. High speed of downloading at 115200bps, compared with the previous version, it is improved by more than 10X.
-  6. Not occupy resources, no limit to simulate 32 I/O ports, serial port, T2 etc.
-  7. Compatible with keilC51 UV2 IDE, support single step, breakpoint, view/modify register, variable, IO and memory data anytime. Support pause during full run, the system will stop at point to the next line to be executed. Support simulation of all kinds of 51family chips, ATMEL, Winbond, INTEL, SST and ST. Support simulation of ALE disable, PCA, double DPTR, and hardware SPI.
-  8. Multi-frequency crystal options: could select 4/11.0592/12/24 MHz as you wish. Solve the unstable issue caused by long crystal cable.
-  9. Designed with system self-testing with speaker and LED indicator, convenient for debugging.
-  10. Designed with long pressing reset button to enter offline running mode, from PC perspective, the simulator works like a real chip on the target board.



51TRACER仿真器连接图  
www.51c51.com

System configuration: one simulator, once USB cable, one 40PIN simulator cap with DIP, one manual, textile bag, one CD( KEIL software evaluation)(If you buy this product with testing instrumental of XLxxxx series from our company, then it is not necessary to buy extra USB cable, simulator cap and the CD.)

Hardware overview:



USB interface: connect USB cable to PC, has the functionality of power supply and communication.

Crystal selection: from left to right, oscillation frequency is 4MHz, 11.0592MHz, 12MHz and 24MHz. One can select any one of them (push up the switch to "ON" position). **Attention: it must have one and only one switch is set to ON, else the simulator may work abnormally.**

State indication: this light is a double-color LED. A single green flash means system reset; Continuous green flash means system running. Red color is for system self-testing, "ON" means low level TTL on P1.0 port.

Reset button: two buttons are the same (one of them is for backup). When assert a short press on it, we can find a single green flash and a sound from speaker, this means the system is reset.

When assert a long press on it (more than 3 second), we can find continuous green flash and two sounds from speaker, this means the system is running offline.




## Chapter Two USB driver installation guide




51TRACER adopts USB communication, please follow below steps to install USB driver.



Step 1: Connect usb socket to usb interface on PC with a usb cable; It is shown founding new hardware wizard; choose “from list or specified location (advanced)”option, and click “next”;




Step 2: choose “include this location for searching” , click “browsing” , switch to CD folder, like “E:\drivers\XLISP driver\USBDRIVER2.0\”, click “next”;



Step 3: it is shown “hardware installation” dialog, if the system prompts “not pass windows icon testing...”,just ignore it, and click “continue”, we can see the software installation is started. When it is shown “complete new hardware wizard” dialog, click “complete”.





 **Step 4:** it is shown “new hardware installation is ready for use” at the right bottom. At this moment, you can see the COM port information at: control panel\system\hardware\device manager, which means USB driver is installed correctly in the system.



#### Tips for installation failure:

If the system exits abnormally or power down during installation, it causes a installation failure. At this moment, you can see the USB device with yellow exclamation mark in the device manager window, just delete it and reproduce above steps to reinstall it.

#### USB installation under special situation:

A normal USB driver installation scenario is like above steps. Under special situation, you may have already installed other USB device, like printer, USB programmer, etc. In this case, the virtual COM port number allocated to our USB maybe COM5, even COM6! However, the KEIL simulation only supports COM1/COM2/COM3/COM4 four ports, how to solve this issue? A stupid solution maybe reinstall the OS and install XLISP USB driver in the new system, there the COM port number is smaller.


 **Figure-1** when plugged with many USB devices on PC, the number is COM5 which is not supported by KEIL software.



Figure-2: move the mouse to the COM5 devices, right click and switch to “property” menu.



Figure-3: click “Port Setting”, then “advanced property”, in the COM option list, select an unused port, like COM2.





Figure-4: system allocated COM3 to USB virtual serial port.



( Simulator connection graph: connect USB to PC, simulation cap to target development board, pay attention to the frequency selection)




## Chapter 3 51TRACER simulator operation guide

51TRACER simulator works with powerful KEIL IDE( in the CD, the evaluation version is provided). If you feel this software is good, you can contact software vendor to get a professional version.

( Due to the complex of the KEIL software, if you are a beginner, please follow below operation guide! )

**Hardware install:** first connect simulator to PC with a USB cable, you will find a sound from speaker and also a green flash on the indicator, which means system testing is OK. Insert simulation cap into target board. Pay attention to insertion direction !



**Software install:** copy CD\developing tool\KEIL to C:\, remove readonly attribute of all files. (must be C:\, other directory does not work)




Execute keil\uv2\uv2.exe.(You can create a shortcut at the desktop as your wish.)



### create your first project (software operation guide):




1.click "Project" menu, select "New Project", input project name, like "test". The extension of the saved file is ".uv2", which is project file extension name of KEIL uVision2.After this, we can click this file to open the project. Attention: DON'T type file extension name. At this moment, it is shown a dialog to choose sing chip type. Let us choose ATMEL---AT89C51. Note we actually use 89s52, it is totally compatible with AT890C52.





2. create ASM source: click "FILE"->"NEW..." to open a text edit window. Input a program like "marqueen lights", then click "FILE"->"SAVE", note the file extension name must be ".asm" such as "C:/prog/001.asm" (Attention: no Chinese character for file name and not more than 8 ASCII chars, make sure the filename is like [1-8 ASCII char].asm)



#### ATTENTION:

Please insert one line before main() function if C code:

```
char code dx516[3] _at_ 0x003b;
```

Please Skip interruption vector area until 0050H if ASM code, like:


```
org 0000H
ljmp main
org 0050H
main: ....; program starting point
```

If you do not follow above instruction, when loading program, the simulator will generate "dididi" alarm sound and the simulation result maybe not correct.

As the development of the single chip machine technology, 00~40H is occupied by more and more new registers, not the original 00~30H. If your program is still 30H, please adjust it to 40H or 50H, 80H. If you have any question about it, please refer the program examples in the CD, they are all tested.


3. click "+" before "Target 1", get to "Source Group 1", right click it and select "Add files Group Source Group 1", load one assemble source file into this project.






4. Simulation part adopts MON51 protocol, please do setting as below before using it:

Click "Project", then click "options for target target 1", click output tab, check "Create HEX file" (generate hexfile) option.




5. click "Debug" tab, select "Keil Monitor-51 Driver", check "load code into simulator" option, check "run to main()" option, In option group "recover debug setting", check "break point", "browsing poing" and "memory display" options.









6. click "Settings" to select COM port. Make it consistent with the actual situation. Your PC may allocate COM2 for your simulation. If you are not sure about it, you can check it at: control panel\hardware\PORT\COM PORT. Meanwhile, please close other software may occupy the COM resources, like serial port debugging software to avoid conflicts. ( If you are using USB communication(not RS232), please choose the virtual COM number that the system allocates.)



7. click icons that shown as below photo to compile the code, (or press down F7) , after successful compilation, you will see the result at the bottom window, like "...0 ( error ) , 0 ( warning ) ".





Beginner may often have error when writing program. Let us change the 3<sup>rd</sup> line from ORG 0080H to RRG 0080H, and do compilation and linking. Due to the syntax error, we can see "001.ASM(3):error A9:SYNTAX ERROR" in the bottom window. Double click this message, locate to error line, after correction, recompile and link until "...0 ( error ) , 0 ( warning ) ".



At this moment, we can see test.hex file is generated under the project directory. Once we have this hex file, we can burn it into the CPU chip by ISP downloading.


Then we can do hardware simulation. Insert simulator cap into 40PIN socket on the target board, and begin simulation.

8. Press down the 3<sup>rd</sup> icon  (debug) as shown in below photo to begin simulator or press Ctrl+F5 shortcut.



It is shown message like “Connected to monitor-51 v9.1”.

(if not, please check the setting carefully.)



(successful connection message for simulation)



Except for viewing the register value, user can also modify them.

For example, change the value of register "A" from 0x62 to 0x85.


Method 1: click register a with the mouse, and then click the value, when prompted with textbox, input 0x85;

Method 2: in the command window, input A=0x85, then press "enter" key to change register A value to 0x85.

#### 6.view/modify memory value

Click menu "View-> Memory Windows", we will see memory window. The Memory Window displays 4 different storage areas. Click window number could switch among them.

In Memory#1 tab, input "D:0e0h" and press "enter" key, we can see memory values are displayed from address E0H. Note, E0H is the address of register A, so the value here is same as register value.




Click "Memory#2" tab, we can monitor another memory area.

反汇编窗口中的值相同。Memory#3 and Memory#4 is the same.


#### Modify data over Memory window

The data in Memory window is modifiable. For example, if we want to modify the value at address 0xE0: move the mouse to the display position, right click the value and select "Modify Memory at D:0xE0", input the data at the dialog.




#### View data by command window

For example, if we want to view data space from address 0x01 to 0x03, we can input "D:0x01,03H" in the command window. D means data space, 0x01 is starting address, 03H is ending address. The data value is displayed in the output window.




### Modify data by command window

For example, if we want to change the value of p1 port from 0x02 to 0x05, only need to input p1=0x04 in command window. Then, we can input d:00h to show if the data is modified.



### 7.view/modify value of variable

When the program pauses, we can view related variables. At monitor/call stack(watch) window, local tab shows current local variables could be seen. "watch" tab shows variables specified by the user. ( press F2 key, let us input variable like "delay")




Move mouse to "delay" and a message indicator pops.

```

x00 ACALL DELay ;
x00 MOV P1,#06DH ;01101101
x00 ACALL DELay ;
x00 MOV P1,#0B6H ;10110110
x05 ACALL DELay ;
x07 AJMP MAIN ;
x00 delay = 0xFF000091 ;延时子程序
x00 d1: mov r7,#255
x00 djnz r6,d2
x07 djnz r7,d1
:0x... ret
x00 end

```

Move mouse to one variable like “d1”, right click it then click (Add “d1” to Watch Windows…), click #1/#2, the variable will occurs at the corresponding watch/call stack(watch) window.



Selected window shows the value of variable d1.

名字	值
d1	C:0x0093
<按F2键可编辑>	


Modify variable method: left click the line of that variable, press F2, input data you want to set.

8.reset

If want to rerun the program, you can click the reset icon and reset the simulator. After resetting is done, the PC counter is set to 0000H. Meanwhile, some internal registers are also reset, like set A to 00H, DPTR to 0000H, SP to 07H, I/O port to 0ffH. At this moment, all the LEDs connected to P1 port on the target board.


9.set break point

Move the cursor to the source line, like “MOV P1,#0B6H” , click the break point icon, we can see a red mark on the left of the line. ( click this mark will remove it.) We can set more breakpoints by this way.



### 10.full run with breakpoints

Press F5 key to start full run, when the breakpoint is encountered, the program will pause at that line. At this moment, you can see values of variables and ports. As below photo: the first breakpoint is after the line “mov p1,#06dh”, input D:000h at the Memory#1 window, we can see the value is really “6D”!




The target board will display the state of current breakpoint. Continue press F5, program pauses at the second breakpoint.


### 11.clear all break points

If want to cancel all breakpoints, clear one by one is awesome, we only need to click this icon to clear all break points in the program.

### 12.run to cursor

Click reset button  start the simulation. Click one line the we want to pause, then click this “run to cursor” icon, we can see program pauses at this line.

### 13.exit simulation

First press down pause icon, then reset and  exit simulation mode. At this time, we can modify the program source, then we can do compilation and simulation.

ATTENTION! Because KEIL software keeps communication with simulator under simulation mode, please better exit as above steps. DO NOT force to exit, else PC will down.






## Chapter 5: FAQ

Why the connection cannot be established under simulation mode?

1. USB driver may have not been setup successfully. Please check if it is OK at: control panel\system\hardware\device manager. If you can see the COM port number information shown like below photo. If not, please reinstall the USB driver or change to another PC and have a try: sometimes, if the USB port number is changed, USB driver should also be reinstalled.



2 Simulation needs KEIL uv2 version 7.0 or higher version, ( Note some early version is not compatible), also the software must be installed under C:\ root directory, can not be other directory! When creating new file, DO NOT save it in other directory, also no Chinese character file name. Please strictly follow [1-8 ascii char].xxx filename style.

3 Make sure the COM port selection is correct (If it is a new system that have not been installed other USB device before, then the COM number should be COM3). Because simulation and programming both need COM port, so when doing simulation, please close XLISP programming or other similar debugging software that may occupy some COM port.

4. Make sure the simulator is reset well. Please press down the reset button. We can find a single green flash and a sound from speaker and this means the system is reset. When assert a long press on the reset button(more than 3 second), we can find continuous green flash and two sounds from speaker, this means the system is running offline.

5. Check if the oscillation frequency is setup OK. One an only one frequency can be set.

6. Check if the simulator cap insertion direction is correct. Pay attention to make the first PIN of the cap(red) align to first pin of the CPU. If the direction is invert, the system may become hot and light is dusky. Please change the direction immediately.

7. Your target board may not works well, maybe no correct clock and reset on it. You can test it by burning a program into the chip, if the burning is OK, it means the target board is correct.

8. Need extra power for target board?



Simulator cap could provide 5v/500ma power supply for the target board, in normal case, it is enough. If you fell it is not enough, you can provide an extra 5V power by yourself. The system is designed for protecting it from too high voltage power supply.



9. Why some port is not active?

Maybe the simulator cap connection is not tight. If possible, please unpack the simulator and have a measure on it by a multimeter.



10. Is the clock and reset of the target board is still functional?

When using 51TRACER simulator, the clock and reset of the target board is taken over by the simulator.



11. Why the program is not stable?

Please insert one line before main() function if C code:

```
char code dx516[3] _at_ 0x003b;
```

Please Skip interruption vector area until 0050H if ASM code, like:

```
org 0000H
```

```
ljmp main
```

```
org 0050H
```

```
main: ....; program starting point
```

If you do not follow above instruction, when loading program, the simulator will generate “dididi” alarm sound and the simulation result maybe not correct.

As the development of the single chip machine technology, 00~40H is occupied by more and more new registers, not the original 00~30H. If your program is still 30H, please adjust it to 40H or 50H, 80H. If you have any question about it, please refer the program examples in the CD, they are all tested.




12. If cannot make certain what is wrong with it, please long press down the reset button to offline running mode. If the program still does not work well, please check your program.



13. If you want to simulate 2051, please refer to the pin definitions of 2051 and 51 and try to make an interface adaptor. Usually, we suggest you just use the 51 simulation and avoid the resources that not exist in 2051.

Below is the photo of simulator-XL2000 connection

(connect USB to PC, simulator to target board, note the frequency)



51TRACER simulating XL2000 photo